4 Channel Constant Voltage Power Repeater

Model No.: EV4-W

4 Channel/PWM signal input/Constant voltage output



Features

CE RoHS emc LVD

- 12-24V constant voltage power repeater.
- 4 channel, 1A per channel, total 4A Max.
- To receive PWM signal control.
- Power repeater in series or in parallel to expand output unlimitedly.
- Apply to RGB or RGBW constant voltage LED strip or module.

Technical Parameters

Input and Output		Safety and EMC	
Input voltage	12-24VDC	EMC standard (EMC)	ETSI ET
Input current	4.5A		ETSI ET
Input signal	12-24V PWM	Safety standard(LVD)	EN 62
Output voltage	4 x (12-24)VDC	Certification	CE,EN
Output current	4CH, 1A/CH Total Max 4A		
Output power	48-96W	Warranty and Pro	tection
Output type	Constant voltage	Warranty	5 yea
	3-	Protection	Revers
Environment			

d EMC	
ard (EMC)	ETSI EN 301 489-1 V2.2.3 ETSI EN 301 489-17 V3.2.4
ard(LVD)	EN 62368-1:2020+A11:2020
	CE,EMC,IVD

,	
irranty	5 years
tection	Reverse polarity

Operation temperature Ta: -20°C ~ +55°C


Case temperature (Max.)	Tc:+85°C
IP rating	IP20

Dimension






Wiring Diagram



AC100-240V Power Supply 12-24VDC VP Constant Voltage RGB LED strip Power Supply 12-24VDC Constant Voltage AC100-240\ EV4-W RGB LED strip



Malfunctions analysis & troubleshooting

Malfunctions	Causes	Troubleshooting
No light	 No power. Wrong connection or insecure. 	1. Check the power. 2. Check the connection.
Wrong color	1. Wrong connection of R/G/B/W wires.	1. Reconnect R/G/B/W wires.
Uneven intensity between front and rear,with voltage drop	 Output cable is too long. Wire diameter is too small. Overload beyond power supply capability. Overload beyond controller capability. 	 Reduce cable or loop supply. Change wider wire. Replace higher power supply. Add power repeater.

Safety & Warnings

- 1. The product shall be installed and serviced by a qualified person.
- 2. This product is non-waterproof. Please avoid the sun and rain.
- 3. Good heat dissipation will prolong the working life of the controller,Please ensure good ventilation.
- 4. Please check if the output voltage of any power supplies used comply with the working voltage of the product.
- Ensure all wire connections and polarities are correct and secure before applying power to avoid any damages to the LED lights.
- 6. If a fault occurs please return the product to your supplier. Do not attempt to fix this product by yourself.